

FLOOR CARE & MAINTENANCE GUIDELINES

Moisture Resistant (MR) Laminate Flooring

Aquastop & Oakleaf HD PLUS

Correct maintenance is a necessary and vital requirement to maximise the performance of your floor. A well-maintained floor will provide many years of service life and add to the overall warmth and charm of the interior décor.

If you follow this industry acknowledged guideline the task of maintaining your floor will become a regular function in the overall upkeep of the property. If you're unsure regarding any of these steps please consult with your flooring retailer to assist with your inquiry.

General maintenance; how to care for your MR Laminate floor.

- Sun Blinds or similar protection must be used for window & door openings exposed to heat and high UV
 exposure; this will assist in reducing the harmful bleaching / fading effects sun damage can have on your
 laminate floor. Constant exposure to UV heat extremes will damage laminate floors if the exposure is not
 controlled.
- Sweep floor regularly with an electrostatic broom, soft bristled broom, or wood floor mop.
- Dust and or clean with a soft bristled vacuum head. Ensure vacuum head is non-abrasive with no metal contact points.
- Remove spills promptly with an absorbent cloth or similar.
- Do not use hard bristled brushes or steel wool scouring pads to clean hard to remove spots or blemishes.
- For all installations avoid placing rugs or mats on the floor surface for at least 2 months. This should enable a more even UV exposure to natural and internal lighting. Avoid animal rugs unless you determine the backing is PH neutral or place carpet / rug lining under to avoid bleaching the floor surface.
- Place mats at exterior and interior doors to trap sand and grit from incoming foot traffic and for drying feet if pool activity is nearby.
- To avoid scuffing & localised scratches, adhere soft pads to the base of all furnishings in contact with the floor. Periodically check to make sure stones or grit have not lodged in any protective pads.
- Keep pets' claws properly trimmed to avoid excess scratches and gouges.
- For sticky spills or ingrained dirt and grime, clean with a well-rung out mop using warm water and a **PH** neutral, non-abrasive floor cleaner, we strongly recommend **BONA** (Stone, Tile or Laminate Cleaner) or LOBA floor care solutions; these are available from reputable flooring retailers & online. Do not use supermarket floor or general cleaning solutions as they are generally concentrated and if used incorrectly will damage the surface coating. Always follow manufacturer's instructions.



Prevention maintenance

- Sun Blinds or window covering protection is required to reduce excessive heat and UV exposure.
- A well-rung out mop is ok to use on moisture resistant MR Laminate flooring. Do not steam mop or excessively wet mop floor surface area after installation. Too much water may cause the planks to swell and warp, this will eventually damage the laminate plank with repeated exposure.
- Do not use waxes or common household supermarket cleaners or detergents on the floor. These • types of cleaning solutions are very abrasive. Long term use will dull the finish and soften the surface coating reducing its durability and sheen level.
- For optimum performance chairs with roller / castor wheels must be placed on protective mats to protect • the surface from excessive grit and point load concentrated wear. Use a rug or matt in high traffic areas to reduce wear & scuffing.
- Do not let sand, dirt or grit build up on the floor surface, sweep regularly.
- When moving heavy furniture or appliances always pick it up rather than rolling or sliding it across the floor. . Use protective floor mats or a lift trolley to avoid floor damage.
- Place drip pans or protective matting under pot plants and animal feeding or bedding areas to avoid . moisture ingress.
- . Importantly, make sure there is a humidity range of 35%- 50% in the room. Long-term exposure outside of this range may result in changes to the flooring surface. For site specific circumstances please consult with your flooring installer or retailer for advice.
- For site related damage such as deep scratching or impact gouges it is possible to uplift individual and surrounding planks to replace any damaged or unsightly flooring. Whenever possible its always important to keep some leftover planks for damage incidents that may occur during the lifecycle of the product.

Disclaimer: we have used all reasonable endeavors to ensure the accuracy and reliability of the information contained herein and, to the extent permitted by law, will not be liable for any inaccuracies, omissions, or errors in this information nor for any actions taken in reliance on this information. Products must be installed in accordance with relevant installation recommendations and industry best practices.

Preference Floors (NSW) ABN 40 117 801 037 32 Britton Street, Smithfield NSW 2164 **t** +61 2 9738 1188 **f** +61 2 9738 1199

Preference Floors (VIC) ABN 34 151 422 927 115 Colemans Road Dandenong South VIC 3175 t +61 3 9794 5111 f +61 3 9794 5133 sales@preferencefloors.com.au vic@preferencefloors.com.au **qld@preferencefloors.com.au**

Preference Floors (QLD) ABN 81 169 158 990 6/268 Evans Road, Salisbury QLD 4107 t +61 7 3875 1688 f +61 7 3875 1788

Preference Floors (SA) ABN 63 600 454 215 47 Research Road, Pooraka SA 5095 t +61 8 8262 2774 f +61 8 8359 4189 sa@preferencefloors.com.au Preference Floors (WA)

ABN 25 625 850 455 3-403 Victoria Rd, Malaga WA 6090 t +61 8 9471 7785 f+61 8 9272 4906 wa@preferencefloors.com.au